




01 Crestron Control Panel




Document Camera Commands



VCR Operating Commands



DVD Operating Commands



PC Selection Commands



Source Preview Monitor



The source preview monitor is placed to the right of the control panel. It shows a preview of the document camera, VCR or DVD inputs. Please refrain from changing the settings of the source preview monitor.

02 Powering System On

- If the touch-screen shows no image, touch it once to activate it.
- Press the <PWR> button to power on the Crestron A/V System. It will take 1-2 minutes for the system to turn on.

03 Projecting from a PC

- You can project from the PC installed in the desk, or from your own laptop. When you press the <PC> input source button, you can make a selection from the touch-screen: "Local PC" (default) or "Laptop".
- To project from a laptop, plug the VGA cable into the VGA output of the laptop, before turning it on. If the VGA cable is not on the desk, check in the lid-covered well.
- If you like, connect the audio cable (attached to the VGA cable) to your laptop as well.

04 Selecting Input

- Input source buttons appear on the left side of control panel screen: <DOC> (document camera), <PC> (local PC or laptop), <VCR>, <DVD>, <OTHER> (any source connected to the video cable).
- Press an input source button to project the desired input. It may take a few seconds for the source to change.

05 Operating VCR & DVD

- When <VCR> or <DVD> input sources are selected, operating commands for the built-in VCR and DVD players appear on the screen (see illustrations above). You can also use the controls on the VCR/DVD player.

06 Operating the Document Camera

- When the <DOC> input is selected, operating commands for the document camera will appear on screen. (You can also use the controls on the document camera device.)
- To adjust zoom and focus, touch and hold the respective <In> or <Out> commands.
- To switch on the document camera lamps, touch <On> above "Lamps". Touch <Off> to switch them off.

07 Adjusting Volume

- Use <VOL ▲> (volume up), <VOL ▼> (volume down) and <MUTE> to adjust the volume of the selected input source.
- Press one of the above buttons and hold it if necessary to increase or decrease volume. You may have to increase the volume to 75% to hear it.

08 Powering System Off

- Press <PWR> to power off the system. You will be prompted with "Are you sure you want to shut down?" Select "YES".
- You will not be able to turn it on again until the system shuts down completely (1-2 minutes).